

CARROLLTON	This section office use only	
CARROLLTON	Date of application #	
	Date of installation	
	Date of receipt of kit	
	Date kit returned	
	HPAC Case #	
Historical Marker Refurbishment	Date before/after inspection	

Data								
Date								
Historical r	marker address							
Name of historical site								
If marker is on private property, written authorization is required from the owner.								
Contact information for person or agency refurbishing historical marker:								
Name								
Address								
Project typ	e:		Boy Scou	its				
			Commun	ity proj	ect			
			Self					
			City					
			Other					
Marker de	scription:		Pole mou	unted				
			Attached to a building					
[
			On private property					
			Other					
Will you need a kit to refurbish the Historical Marker? ☐ Yes ☐ No If yes, call Planning to check out a kit. 972-466-3040								
Check for additional checklist information on reverse side of application								
Name						Signatur	е	
Phone				Email				

Refurbishing Texas Historical Markers

Information from You Tube: http://www.youtube.com/watch?v=yCzbCRiJhbs

Information from state Website:

Here are the tools and materials you need to clean or repair the surface of a marker:

- Stiff wire brush
- Soft bristle scrub brush
- Spray bottle or bucket of water
- Soap
- Towel
- Can of black lacquer spray paint

- Can of clear lacquer spray paint
- Cotton rags
- Lacquer thinner
- 80 grit and 120 grit sandpaper
- Power sander or hand sanding block
- Roll of two-inch painter's masking tape



Step 1:

Use a stiff wire brush to remove flaking or other debris; always use a side-to-side or left-to-right motion while cleaning the surface.



Step 2:

Use a soft bristle brush to remove dust and other debris around letters. If available, use a portable air blower to remove fine particles.




Thoroughly clean the marker surface with soap and water. Towel dry and allow time for the marker surface to dry completely.



Step 4:

Apply two inch painter's masking tape to the border and base of the marker.



Step 5:

Apply two even coats of an automotive black lacquer (spray) to the entire surface of the marker. Allow the black lacquer to dry completely. Use a painter's mask to avoid inhalation of spray paint.

Step 6:

Remove dried black lacquer from the medallion and title letters with a soft cotton cloth and lacquer thinner. Use care not to remove the black lacquer on the flat surface portions of the medallion and area surrounding title letters. Allow marker to dry completely.



Step 7:

After removing masking tape from the marker border and base, use a battery-powered or electric sander and 80 grit sandpaper or a hand sanding block to remove black lacquer from raised text. Use care not to remove black lacquer from flat surface areas. Lightly use the sander to clean marker border and base. Use 120 grit sandpaper to manually polish border and raised medallion.



LITTLEFIELD HOME GEORGE W LITTLEFIELD O TIXAS WITH HIS FAMILE E SERVED IN THE CIV ERBY'S TIXAS RANGE HE RANK OF MAJOR AR HE BECAME A COUIRED RANG AND THE TEXAS J. HIRANDLE HE D AUSTIN IN 1883 AND ENGAG MKINGA REGIST OF THE UNIV F TEXAS, 1911-1920, HE CONTRI JINDS FOR NEW BUILDINGS. S RANTS AND LIBRART COLLEGE TILEFIELD BUILT THIS VICTO TILEFIELD BUILT THIS VICTO

Step 8:

Remove fine debris with paint or bristle scrub brush. If available, use an electric or battery-powered air blower to remove fine debris.



Step 9:

Apply two even coats of clear lacquer spray paint to the entire surface of the historical marker.

Step 10:

Step back and admire your work; you now have a historical marker that has been renewed to its original splendor.

